



TITAN

ACOUSTIC SLAT WALL

ACOUSTIC SLAT WALL INSTALLATION GUIDE

Step 1:
Prepare all the tools and materials you need.

Step 2:
Measure the height of the wall.

Step 3:
Cut the panel according to the acoustic height of the wall.

Step 4:
Place the acoustic panel on the wall and nail it.

Step 5:
Install in turn, Measure the remaining width.

Step 6:
Cut the acoustic panel into the remaining width.

Step 7:
Use an edge strip at the edge. Glue the edge of the acoustic panel and stick the edge strip firmly at the gluing place.

Step 8:
When dealing with external corner, Use an edge strip too.

Step 9:
Complete the installation.

a. Nail acoustic panels directly to the wall.
Absorption Class: D

b. Attach acoustic panels to the wall with nail-free glue.
Absorption Class: D

c. Install fibreglass wool or rock wool between the battens.
Absorption Class: A